

MARKETED AND DISTRIBUTED BY  
Cummins

# DATUM Z

## DATA AUTOMATED TELLER ULTIMATE MACHINE



MARKETED AND DISTRIBUTED BY  
**Cummins**




## DATUM SPECIFICATIONS



DATUM MODEL	TANK CAPACITY	LENGTH (MM)	WIDTH (MM)	HEIGHT (MM)	WEIGHT (KG)
Z	1000 litres	1810	1775	1935	950
Z	2000 litres	2526	1775	1935	1150

## PLATFORM SPECIFICATIONS




- **Concrete base with the below mentioned dimensions**  
DATUM is not to be placed on loose soil
- **Shed**  
To protect the DATUM's manhole - To be constructed/installed after the placement of DATUM on the platform to avoid any issues with the height
- **Please note**  
There should be no overhead electric cable or high tension electric line

PLATFORM DIMENSIONS	
Length	10 ft.
Breadth	10 ft.
Height	1 ft.


MARKETED AND DISTRIBUTED BY  
**Cummins**



## SAMPLE SITE PHOTOS



# SITE SOPS






## Electricity Supply & Servo Stabilizer

- An **electricity supply point** right beside the DATUM
- **20 mm X 610 mm (minimum) cylindrical copper rod** for earthing connection



SERVO STABILIZER SPECIFICATIONS	
<b>Capacity</b>	5 KVA Single Phase
<b>Input</b>	170-270 V AC Single Phase
<b>Output</b>	230 V AC +/- 1% Single Phase

# DATUM UNLOADING



					
<p>■ Check the weight of the load. Never overload and do not exceed Working Load Limit.</p>	<p>■ Take into account the lifting configuration and the lifting angle.</p>	<p>■ Consider the centre of gravity of the load.</p>	<p>■ Never hang the slings on the hook tip.</p>	<p>■ Protect slings from sharp edges.</p>	<p>■ Never tie knots.</p>
					
<p>■ Use slings at temperatures ranging from -40°C to +100°C.</p>	<p>■ Consult manufacturer in case of chemical exposure.</p>	<p>■ Consider hook dimensions. If necessary use shortening hook.</p>	<p>■ Destroy and replace slings as soon as the wearing indicator is visible (available on MEGA round slings only).</p>	<p>■ Make sure the load is uniformly distributed on the whole sling width.</p>	<p>■ Connect slings together using appropriate loops and metal rings only.</p>

**WARNING : in case of chemical exposure consider following factors**

			
Type of chemical	Concentration	Temperature	Duration of chemical exposure

**Instructions of use**

- Operate round slings and flat slings within the permissible temperature range.
- Ensure that sling is protected from any sharp corners and/or abrasive surfaces, use either protective polyester, polyurethane sleeves or coatings.
- Storage : in a cool place, away from humidity and sunlight.
- Never dry sling near a fire or any source of heat.
- **DO NOT USE DAMAGED SLINGS.**



# THANK YOU

For any queries, please contact:



**Karm Sales And Service Pvt. Ltd.**

[www.karmsales.com](http://www.karmsales.com)  
Barkat Plaza, Ring Road No 02,  
Hirapur Raipur (C.G) - 492010  
+917898001670  
Powered By:

